



# TONONE




ELLA

Handleiding  
User manual


1




2




3



4



5



Deze handleiding is bedoeld voor gebruikers van de Tonone Ella lamp. Voor optimaal gebruik van de Ella lamp adviseren wij u deze handleiding zorgvuldig door te lezen. Wij adviseren de handleiding op een veilige plek en binnen handbereik te bewaren.

Met dit symbool wordt informatie aangeduid die belangrijk is op te volgen omdat, wanneer de informatie niet juist wordt opgevolgd, er een gevaarlijke situatie kan ontstaan die mogelijk letsel tot gevolg zou kunnen hebben.



## 1 Inleiding

### 1.1 Beschrijving van het product

Dit product is alleen bedoeld als verlichting voor binnen voor privé gebruik. Het is niet de bedoeling het product op andere manieren te gebruiken of veranderingen aan het product aan te brengen, dit kan onjuist gebruik veroorzaken welke risico's op ongelukken met zich mee brengen. De producent is niet aansprakelijk voor schade op welke manier dan ook veroorzaakt door onjuist gebruik van het product. Het is niet de bedoeling het product voor commerciële doeleinden te gebruiken.

### 1.2 Gebruikte symbolen



De afkorting CE staat voor Conformité Européenne en betekent dat de Ella lamp aan de Europese eisen voldoet.



Heavy: Let op! De kap en het armatuur zijn zwaar. Houdt hier rekening mee bij het plaatsen.



Klasse II: De elektrische onderdelen van de Ella lamp zijn dubbel geïsoleerd. Het onderdeel hoeft niet geaard te worden.



Breekbaar: Het wordt aanbevolen voorzichtig met de lamp in verpakking om te gaan bij transport, zodat de lamp zonder beschadiging aankomt bij bestemming.



Afvalscheiding: De Atlas lamp mag niet worden verwijderd als ongesorteerd stedelijk afval, maar moet gescheiden worden ingezameld. Bijv. bij de milieustraat van de gemeente.



Deze kant boven: Het wordt aanbevolen de pijlen op de verpakking omhoog te laten wijzen bij transport, zodat de lamp zonder beschadiging aankomt bij bestemming.



Recycling: Met als doel de inzameling, het hergebruik en de terugwinning te vergemakkelijken, wordt t.b.v. de identificatie en classificatie door de betrokken industrie de aard van het gebruikte verpakkingsmateriaal of de gebruikte verpakkingsmaterialen op de verpakking aangegeven. 20 PAP staat voor golfkarton.



Droog: Het wordt aanbevolen de verpakking droog te houden bij transport, zodat de lamp zonder beschadiging aankomt bij bestemming.

## 2 Veiligheidsinstructies

- De lamp is vervaardigd uit metaal en kan scherpe randjes hebben.
- Plaats de lamp niet op hete oppervlakten.
- Om veiligheidsredenen en volgens de garantievoorwaarden dient u het product niet te demonteren.
- U dient de stekker niet te openen.
- De lichtbron kan heet worden.
- De lamp is niet geschikt voor kinderen onder de 8 jaar.
- Houd de stekker en de lamp vrij van vocht. Gebruik de lamp niet in combinatie met water of vochtige ruimtes.



## 3 Installatie en montage van de lamp

Let op!


De kap van de lamp is zwaar. Het messing is zeer gevoelig voor aanslag door vocht en vettigheden.



1. Trek de meegeleverde handschoenen aan.
2. Draai de lichtbron in de fitting.
3. Plaats de kap op het armatuur.
4. Steek de stekker in het stopcontact.
5. Zet de lamp aan met de dimschakelaar.

## 4 Dimmer waarde instellen

Instelmogelijkheid aan de achterkant van de dimmer. Schakel het licht in met een druk op de knop. Draai de pijl tegen de klok in naar de positie "Min." en stel met de knop de gewenste minimale waarde in. Draai de pijl met de klok mee naar de positie "Max." en stel met de knop de gewenste maximale waarde in. Draai de pijl vervolgens naar de middelpositie "0".



## 5 Onderhoud

### 5.1 Schoonmaken

Haal de stekker uit het stopcontact wanneer u de lamp schoon wilt maken. Voorkom krassen en reinig het armatuur alleen met een zachte droge doek. Gebruik geen schoonmaakmiddelen.

Reinig de kap wanneer deze van het armatuur is verwijderd. De kap is niet vaatwasser bestendig.

### 5.2 Reparaties

Vervangen van de lichtbron:

- Schakel de lamp uit met behulp van de drukschakelaar.
- Draai de lichtbron los en vervang deze door een nieuwe lichtbron. E27 lichtbronnen van iedere energieklassen zijn geschikt voor de Ella lamp.
- Zet de lamp aan met behulp van de dimschakelaar.

Uw lamp is kapot:

#### Let op!

Voer zelf geen reparaties uit wanneer uw lamp kapot is. Neem contact met ons op via [info@tonone.com](mailto:info@tonone.com) of bel +31 (0)85 782 13 33



## 6 Milieu

### 6.1 Inleveren en recycling

Informeer binnen uw regio naar de mogelijkheden om de Ella lamp in te leveren bij beëindiging van het gebruik. Gooi elektrische apparaten en onderdelen niet weg, maar bekijk of (onderdelen van) Ella ingeleverd, gerecycled of hergebruikt kunnen worden.

### 6.2 RoHS-naleving

Dit product voldoet aan richtlijn 2002/95/EC van het Europese Parlement en de Raad van 27 januari 2003 aangaande de beperking van het gebruik van bepaalde milieugevaarlijke stoffen in elektronische apparatuur (RoHS) en de aanpassingen van die richtlijn.

### 6.3 WEEE-kennisgeving

De WEEE-richtlijn (Waste Electrical and Electronic Equipment), die als Europese wet van kracht werd op 13 februari 2003, heeft geresulteerd in een belangrijke verandering in de behandeling van elektrische apparatuur aan het einde van hun gebruiks-cyclus. Het doel van deze richtlijn is ten eerste het voorkomen van elektrische apparatuur in het afval en bovendien het bevorderen van hergebruik, recycling en andere vormen van herstel van dergelijk afval teneinde de hoeveelheid afval te beperken.



Het WEEE-logo op een product of op de verpakking geeft aan dat dit product niet samen met het huishoudelijk afval mag worden afgevoerd of weggegooid. U dient al uw oude elektronische of elektrische apparatuur af te voeren via speciale verzamelpunten van dergelijk gevaarlijk afval. Afzonderlijke inzameling en correcte behandeling van oude elektronische en elektrische apparatuur helpt ons natuurlijke bronnen in stand te houden. Bovendien waarborgt de correcte recycling de veiligheid en gezondheid van de mens en zijn omgeving. Voor meer informatie over het verwerken van elektronische en elektrische apparaten, hergebruik en verzamelpunten, neemt u contact op met uw gemeente, uw plaatselijk milieubedrijf, de winkel waar u het apparaat heeft gekocht of de fabrikant van het apparaat.

This manual is intended for users of the Tonone Ella lamp. Please read this manual carefully for correct use of the Ella lamp. We recommend that you keep this manual in a safe place and within easy reach.

This symbol indicates important instructions that must be followed to avoid potentially dangerous situations from arising, as well as to prevent any damage.



## 1 Introduction

### 1.1 Product description

This product is exclusively intended as source of lighting for private, indoor use. We do not recommend the product be used differently or that it be modified. This may result in incorrect usage and may lead to accidents. The manufacturer is not liable for any damage caused by incorrect usage of the product. The product is not intended for commercial purposes.

### 1.2 Used symbols



CE marking: CE stands for Conformité Européenne and means that the Ella lamp meets the requirements of European quality standards.



Heavy: Please note that the lamp shade is heavy to lift. Please take this weight into account when installing the lamp.



Class II: Appliance class II: The Ella lamp is a double insulated appliance.



Fragile: Please handle the packaged lamp with care during transportation to ensure it reaches its destination undamaged.



Waste handling: The Ella lamp requires special waste handling and may not be placed in unsorted waste for removal. Please contact the local authorities for collection or visit the municipal waste collection facility.



This side up: Please ensure that the arrows on the packaging point upward to ensure the lamp reaches its destination undamaged.



Recycling: The materials and substances used in the packaging materials of the products are listed on the packaging to aid identification and classification by the relevant authorities and to aid collection, recovery, reuse and recycling. 20 PAP is the recycling symbol for cardboard.



Dry: Please ensure that packaging does not come into contact with any liquids to ensure the lamp reaches its destination undamaged.



## 2 Safety instructions

- The lamp is made of metal and may have sharp edges.
- Please do not place the lamp on hot surfaces.
- For your own safety and to comply with warranty conditions, please do not disassemble the product.
- Please do not open the plug.
- The light bulb may be hot.
- The lamp is not suitable for children below 8 years of age.
- Please do not expose the power cord or lamp to moisture. Do not expose the lamp to water or use in damp spaces.



## 3 Installing and assembling the lamp

### Pay attention!


- The lamp shade is heavy to lift.
- The brass is very sensitive for impact by moisture and greasiness.



1. Pull on the included gloves.
2. Screw the light bulb into the fixture.
3. Install the shade on to the luminaire.
4. Plug the power cord into the power outlet.
5. Turn on lamp using the dimmer switch.

## 4 Dimmer value settings

Specify setting on the rear side of the dimmer. Switch on light by pushing the button. Turn the arrow in an anticlockwise direction to "Min." and specify the desired minimal value by pushing the button. Turn the arrow in a clockwise direction to "Max." and specify the desired maximum value by pushing the button. Finally, turn the trimmer to the middle position "0".



## 5 Maintenance

### 5.1 Cleaning the lamp

Always remove the power cord from the outlet before cleaning your lamp. Avoid scratches and clean the luminaire with a soft dry cloth only. Always wear the included gloves to prevent pollution off the brass. Do not use detergents.

Only clean the shade when it is removed from the luminaire.  
The shade can't be cleaned in the dishwasher.

### 5.2 Repairs

Replacing the light bulb:

- Turn off the lamp using the pressure switch.
- Unscrew the light bulb and replace it with a new bulb. E27 light bulbs of any energy class are suitable for the Ella lamp.
- Turn on the lamp using the dimmer switch.

Your lamp is damaged:

#### **Pay attention!**

Do not try to repair your lamp when it's broken or damaged.  
Please contact us at [info@tonone.com](mailto:info@tonone.com) or call +31 (0)85 782 13 33



## 6 Environment

### 6.1 Collection and recycling

Please note that the Ella lamp requires special waste handling and may not be placed in unsorted waste for removal. Do not throw away electrical appliances and components. Find out whether the Ella lamp (or its components) can be collected, recycled or reused.

### 6.2 RoHS compliance

This product meets the requirements of Directive 2002/95/EC of the European Parliament and the Commission of 27 January 2003 concerning restrictions of certain hazardous substances in electrical appliances (RoHS) and the amendments to that directive.

### 6.3 WEEE-kennisgeving

The WEEE (Waste Electrical and Electronic Equipment) Directive, which came into effect in Europe on February 13, 2003, has resulted in a fundamental shift in the processing of electrical equipment at the end of their life cycle. The directive is intended to reduce the amount of electrical appliances and electronic equipment that ends up in landfill and, to that end, ensure that such equipment is recycled, reused or recovered in other ways.



A WEEE logo on a product or on its packaging means that the product may not be disposed of or collected with ordinary household waste. All old electronic or electrical appliances must be disposed of at special collection facilities for hazardous waste. Separate collection and correct processing of old electronic and electrical equipment will help us maintain our natural resources. In addition correct recycling goes to benefit the safety and health of mankind and the environment. To find out more about the processing and collection of electronic or electrical equipment, about reuse or collection facilities, please contact the municipality, the local waste management company, the store at which you purchased the appliance or the manufacturer of the appliance.

# Tonone

Veemarktkade 8 – 6117  
5222 AE Den Bosch  
The Netherlands  
[info@tonone.com](mailto:info@tonone.com)  
[www.tonone.com](http://www.tonone.com)